

## FOUNDATIONS FOR KNOCK DOWN REBUILD PROJECTS



## **HOW WE WORK**



**WE GO THE EXTRA MILE TO GIVE YOU PEACE OF MIND.** 

STEP 1


Review your structural drawings and GeoTech report to provide an accurate cost estimate.





STEP 2 Mark-out the job to ensure precise screw pile location.

STEP 3







STEP 4 Install your screw piles to required torque measurement.



STEP 5 Certify the installation with Engineers using our mobile installation reporting app.

FOR KNOCK DOWN REBUILDS. CALL US NOW.

1300 64 64 23

LEARN MORE nomoredigging.com.au





